

Fourcon-Trol™ Passenger Floor Board Kit Installation Instructions

NOTE: *We do not recommend installing passenger floor boards on lowered motorcycles.*

This kit contains:

- Passenger floor boards, left and right
- A mounting bracket
- A round bar brace
- Four U bolts with washers & nuts
- Two 3/8" bolts with washers and nuts



Minimum tools required: 4mm allen wrench; 7/16" deep drive socket and ratchet; 9/16" socket; 9/16" open/box end wrench.



1. Remove the right side battery box cover.



2. Remove the right lower frame cover.



3. Remove the chrome cover behind the pipes.



4. Brake side- Place two U bolts over the frame just ahead of the brace connecting the upper and lower frame members.

5. Raise the rear floor board bracket into position and slide the U bolts through the holes in the bracket. The small tabs of the bracket point up and the tabs with the large holes point toward the rear wheel. Install a plate, a flat washer, a lock washer and a nut on each stud. Do not tighten the nuts yet.



6. Shifter side- Though not necessary it is helpful to remove the chrome access cover on the shifter side. Place two U bolts over the frame just ahead of the brace connecting the upper and lower frame members.

7. Raise the rear floor board bracket into position and slide the U bolts through the holes in the bracket. Install a plate, a flat washer, a lock washer and a nut on each stud. Do not tighten the nuts yet.



8. Slide a foot board into the large hole. Install a 3/8" bolt with a washer in the bracket. Place a nut and lockwasher on the bolt. Do not tighten.



9. Slide the round bar brace through the opposite bracket and into the foot board tube on the other side. Push it until it will go no farther.

Slide the other foot board over the bar brace and into the large hole. The tolerances are close so you may have to wiggle it some to slide into place. Install a 3/8" bolt with a washer in the bracket. Place a nut and lockwasher on the bolt. Finger tighten.

The angle of the floor boards can be adjusted at this point. Installing the bolt in the bottom hole places them flat, placing the bolt in the top hole sets the boards at an angle.



10. Align the bar brace on both sides to the square frame member. The bar brace should be directly below it. Treat the U bolt studs with blue lockite and evenly tighten all the nuts on the U bolt studs. Fully tighten the floor boards to the brackets. Replace all the covers.