

INSTALLATION TIPS
PN# 133
FINNED HORN COVER



FITMENT: All left side between cylinder mount or custom applications

1. **IMPORTANT-Do Not** allow fins of horn cover to come in contact with cylinder fins. On some Twin Cam models it may be necessary to add some washers to the stock rubber mount. A minimum of a half an inch clearance is needed For best effect you may choose to add a couple of washers both behind and in front of the rubber mount.
2. For a very clean look we recommend you cut the stock chrome horn strap at the bend and install it so that it covers the strap of the new horn.
3. Some newer models have large rubberized connectors to the horn, these may be difficult to connect. You may wish to replace these connectors with some smaller ones for a better fit.