

USING CHRONOGRAPH FUNCTIONS

The chronograph functions are operated by pressing the and B buttons on the side of the case.

STANDARD TIMING

To measure how long an event takes, simply push button A to stop and start the stopwatch, which displays time in the subdials (center second hand ; and minutes in sub-dial up under 12 O'clock), and use button B to reset.

ELAPSED TIME MEASUREMENT

To record elapsed time, use button A to start, stop and restart as often as required. Use button B to reset after the match is over.

SPLIT TIMING

Press button A at the start of the event. Press B to check the time for one segment of the event, then press B again to return to a display of total elapsed time. Press A at the end of the event, then use B to reset.

TIMING TWO SIMULTANEOUS EVENTS

Press button A at the start of the events. Press button B to see the time for the first event. Press A when the second event finishes, then press B to see the total elapsed time. Reset by pushing B again.

HOW TO RESET 24 hr REGISTER**

Sometimes the 24 hr sub-register does not agree with the hour hand. You can try to reset it by *rapidly* advancing the minute hand until you notice that the 24 hr hand has come back to its proper setting.

NB: This may take several complete rotations of the minute hand if it works at all.

*** Attempt this at your own risk. Although this works for some people, we have no way of knowing if this can possibly damage the mechanism.*

HOW TO ADJUST HAND POSITION

If your chronograph hands will not return to the 12 o'clock position when chronograph is reset or when the battery is replaced, follow this procedure to reset the hands to 12 o'clock:

- 1: Pull crown (C) out to the second click
- 2: Press button B to reset chrono minute hand to 12 o'clock position **
- 3: Press button A to reset chrono second hand to 12 o'clock position **
- 4: Push crown (C) back in to the normal position.

** hand moves quickly if the button is kept pressed

SETTING TIME AND DATE

To set the date on your watch, gently pull the crown out to the first click position. Rotate the crown clockwise (toward the top of the watch face). The date on the watch will advance. If the number showing in the window is too high, go past 31, and the counter will start at 1 again.

Stop one day before the correct date. Next, pull the crown out another stop and turn it clockwise so the hands move forward. When you pass 12, the date should change automatically to the correct date. If you are setting the watch before noon, stop as soon as you get to the correct time and push the crown all the way back in.

If you are setting the watch after noon, go past 12 again before you stop at the correct time and push the crown all the way back in.

Seiko Chrono Gen. 2 7T27 7A20

